

ELECTRIC SCREEN ACCESSORIES

Key-Locking Switch Cover Plate



- Hinged, goes over cover plate.
- Opens with a key to allow access to 110 volt switch or L.V.C. three-button wall switch.
- Brushed stainless steel finish.

Key-Operated, 110 volt Switch



- Flushed-mounted wall control switch is key-activated for security.
- Use with 110 volt systems only.
- Ivory cover plate.

Video Projector Interface



- DC controls allowing screen to be raised or lowered automatically when projector is ON or OFF. Two models to choose from: 12 volt or 5 volt.
- Includes complete box with ivory rocker switch for manual operation and cover plate.
- Projector must have a 12 volt or 5 volt lead to operate the interface.

Wireless Remote for Horizon

- Radio Frequency
- Remote
 - Infrared Remote



Replacement Wall Switches 110 volt

- Ivory
- White



Floating Mounting Bracket for Cosmopolitan and Tensioned Cosmopolitan

Allows screen to be mounted onto wall or ceiling and aligned left to right.

- White
- Black



Laser Pointers

The ultimate in presentation convenience. Select from three models.

- Laser Pointer
- Blinking Mode Laser Pointer
- Jumbo Laser Pointer

